




Lenovo Student Computers - Staff Guide

Power Button

This can be located on the right hand side on the rear of the computer as marked below. Press once and wait for computer to boot.




Adjusting Volume

Holding the [Fn] Key press [F1] to mute all sounds, [F2] to decrease volume and [F3] to increase volume. The volume cannot be adjusted in Windows 11.



Headphone Connection

Headphones can be plugged in to the computer via the connection located under the screen as marked below.



Webcam & Microphone

The Student Computers are equipped with a Webcam and Microphone, these can be enabled by gently pulling up from the top of the computer. **Please ensure they are pushed back down after use to help protect from accidental damage.**

